

Basic – E CONTROLLER

For Customer Support Questions:


Ph. (859) 626.3001

Fax. (859) 626.3001

Email. support@greenhousetechnology.com

Modes:

Press the
Mode Button
and ----



---- Press the up or
down arrow to display
the mode you want.

Modes Available:

Pass: Program the boom to make a certain number of passes.

Delay: Program the boom to make a single pass at pre-defined intervals during certain times of the day or night.

Jog Forward: To move the boom forward.

Jog Reverse: To move the boom backward or in the reverse direction.

Home: Move the boom to the home position

Away: Move the boom to the away position


Location: Program the boom to know its current location in the bay.

Time: Display current time

Test: Test boom hardware

MODE: PASS

Once You Display
the PASS Mode
You ----



---- Press the Select Key to Program the
Pass Mode or Press the Run Key
to Start the Mode.

Select Press

PASS: 02

Press up or down
arrow to increase
or decrease the
number of passes
Range = 1 - 99

Select Press

SPEED: 12

Press up or down
arrow to increase
or decrease speed.
Range = 1 - 24

Select Press

AWAY: 1 - -

Press up arrow key
to select valve and
press lower arrow
to move to next valve
position.
Valves = 1,2,3

Select Press

HOME: - 2 -

Press up arrow key
to select valve and
press lower arrow
to move to next valve
position.
Valves = 1,2,3

Select Press

MODE: PASS H


Run Press

Pressing run will start
the boom running.
The boom will make
2 complete passes
at speed 12 from the
home position to the
away and back
again. The valve 1
will be on in the away
direction and the valve
2 will be on in the home
direction.

Note: You can stop the
boom by pressing the run
button again.

MODE: DELAY

Once You Display
the DELAY Mode
You ----



---- Press the Select Key to Program the
Delay Mode or Press the Run Key
to Start the Mode.

Select Press

TIME ZONE: 1

Press up or down
arrow to select the
Time Zone you want
to edit. Range = 1 - 3

Select Press

START TIME:08:00

Press up or down
arrow to change the
time to the start time
for Time Zone 1

Note: Press and hold the
arrow key down and the time
will change quickly. Time is
in military.
Range = 00:00 - 24:00

Select Press

END TIME:17:00

Press up or down
arrow to change the
time to the end time
for Time Zone 1

Note: Press and hold the
arrow key down and the time
will change quickly. Time is
in military.
Range = 00:00 - 24:00

DELAY: 015

Press up or down
arrow to select the
interval or time between
passes. Range: 1-240
Minutes

Select Press

SPEED: 12

Press up or down
arrow to increase
or decrease speed.
Range= 1 - 24

AWAY: 1 - -

Press up arrow key
to select valve and
press lower arrow
to move to next
valve position.
Valves = 1,2,3

Select Press

HOME: - 2 -

Press up arrow key
to select valve and
press lower arrow
to move to next
valve position.
Valves = 1,2,3


TIME ZONE: 2

*At this point you can
program additional time
zones repeating the
previous steps, start
the boom by pressing
the start button or
change modes by
pressing the mode
button and using the
arrow keys to change
modes.*

*Note: If you start
the boom and need
to stop it, you can
stop the boom by
pressing the run
button again.*

MODE: JOG FORWARD

Once You Display
the JOG FORWARD
Mode You ----




---- Press the Run Key to Jog the
Boom Forward

Run Press

Press RUN to start
the boom.

You can adjust Boom
SPEED in Jog Forward
Mode.



SPEED: 12


Press up or down
arrow to increase
or decrease speed.
Range= 1 - 24

Run Press

Press RUN to Stop
the boom.

MODE: JOG REVERSE

Once You Display
the JOG REVERSE
Mode You ---




---- Press the Run Key to Jog the
Boom in Reverse



Press

Press RUN to start
the boom.

You can adjust Boom
SPEED in Jog Forward
Mode.



SPEED: 12



Press up or down
arrow to increase
or decrease speed.
Range= 1 - 24




Press

Press RUN to Stop
the boom.

MODE: LOCATION

Once You Display
the LOCATION
MODE You ...



----- Press the Run Key to Jog the
Boom Forward

Run Press

Press RUN to set the
current boom location.

BOOM LOCATION H

Press up or down
arrow to change the
current boom
location.

H = Home
C = Crop
A = Away


You want the boom
location on the con-
troller to match the
actual location of the
boom in the bay.

Run Press

Takes you back to the
mode screen.

MODE: LOCATION H

SETTING CLOCK



▶ Press

Note: Unplug Controller and then Power-up the Controller while pressing the Down Arrow Key.

TIME: *00:00

▶ Press the up or down arrow key to increase or decrease the hours.

Select

Press the Select key to move the asterisk to the Minutes. Press the up or down arrow key to increase or decrease the minutes


CURRENT TIME IS
IN MILITARY USING
00:00 - 24:00

Run

Press Run to go to the mode screen.

MODE: TEST

Once You Display
the PASS Mode
You ----



---- Press the Select Key to Program the
Pass Mode or Press the Run Key
to Start the Mode.

Run
Press

VALVES: - - - H

Press the up arrow
key move between
valve 1,2,3 and
the down arrow
key to turn on the
valves.

After the 3rd valve you
will see the following
screen

SWITCH: 123456 H


Each number represents
a magnet read switch.

- 1 = Motion
- 2 = Job Forward
- 3 = Job Reverse
- 4 = Collision
- 5 = Remote Start
- 6 = Index

At this point if you place
a magnet near one of
the magnet switches
the number corresponding
to that switch should
appear on the screen.

This is an excellent screen
when you need to trouble
shoot a sensor or make
sure you have the sensors
wired correctly.

ENABLE / DISABLE MOTION ALARM





Press Run to go to the mode screen.


Note: Unplug Controller and then Power-up the Controller while pressing the Up Arrow Key.

Note: Under normal circumstances the motion alarm should be enabled!

MOTION ENABLED

-  Press the up or down arrow key to Enable or
-  Dis-Able The Motion Alarm

RE-SETTING CONTROLLER



Select Press

Run Press Run to go to the mode screen.

Note: Unplug Controller and then Power-up the Controller while pressing the Select Key.

Note: This key will reset the controller to factory original.

BATRAM CORRUMPT